




prestige Solo 399

Concentric Vent/Air System Supplement



WARNING

This document is intended to be used by a qualified heating contractor or service technician. Read all instructions within this document and within the PRESTIGE Boiler Installation and Maintenance Manual, before proceeding with the installation. It is recommended to follow the procedures in the steps given, skipping or missing procedural steps could result in severe personal injury, death or substantial property damage.

NOTICE

Installation of this boiler must comply with local requirements and codes and with the National Fuel Gas Code NFPA 54, ANSI Z223.1 for installations within the U.S. For installations in Canada the installation must comply with CSA B149.1 or B149.2

PRODUCT AND SAFETY INFORMATION

Definitions 1

SECTION I - PRE-INSTALLATION ITEMS

General Requirements 2
Vent/Air System Kit Components 2
Assembled Vent/Air System Kit Dimensions 3
Optional Vent/Air System Components 3

SECTION II - VENT/AIR SYSTEM INSTALLATION

Vent/Air System Clearance Requirements 4
Determine Termination Location 4
Boiler Vent/Air System Adapter 5
Vent/Air System Joint Assembly 5
Termination Installation 6
Cutting Termination Fitting to Length 7
Adjustable Length Vent/Air System Pipe 7
Fire Stop Support Plate 8
Multiple Vent/Air System Terminations 8

SECTION III - MAINTENANCE PROCEDURES

Inspect Vent/Air System 9

Definitions

The following terms are used throughout this manual to bring attention to the presence of potential hazards or to important information concerning the product.

WARNING

Indicates a potentially hazardous situation which, if ignored, can result in death, serious injury or substantial property damage.

NOTICE

Indicates special instructions on installation, operation or maintenance, which are important to equipment but not related to personal injury hazards.

NOTICE

This supplement is intended for the installation of a Concentric Vent/Air System with a Prestige SOLO 399 Boiler. The Concentric Vent/Air System is not intended for installation with any other Prestige Boiler.

NOTICE

This Vent/Air System is listed to ULCS636 as Type BH Class IIC Vent System with a 110°C (230°F) maximum flue temperature rating under Intertek/ETL Report number: 3122286

NOTICE

Triangle Tube reserves the right to modify the technical specifications and components of its products without prior notice.

SECTION I - Pre-Installation Items

General Requirements

Installation of the vent/air system must comply with local codes and requirements and with the National Fuel Gas Code NFPA 54, ANSI Z223.1 for installations in the U.S. For Installations in Canada, the installation must comply with CSA B149.1 or B149.2.

The vent/air system must be fully constructed using **ONLY** the Prestige Concentric Vent/Air System components from Triangle Tube. Do not mix other vent components or joining methods from other manufacturers.

WARNING

Do not mix vent components or joining methods from any other vent manufacturer with Triangle Tube's Prestige Concentric Vent/Air System. Failure to comply with this requirement could cause vent failure resulting in leakage of flue products into the living space of the building.


Do not connect more than a single boiler into the vent/air system.

All penetrations of the vent/air system through ceilings, floors or walls must be properly fire stopped. Check with local codes and requirements regarding fire stops and vent penetrations.

The vent/air system must not penetrate or be routed through any active vent system or chimney.

Vent/Air System Kit Components

Prior to installation of the vent/air system check to ensure all parts required for the completion of the system are present. See Figure 1 for complete breakdown of concentric vent/air system kit parts and Fig. 3, page 3 for optional components.



Note: Mounting Hardware Not Shown

Fig. 1: Concentric Vent/Air System Kit Components - PSVKIT03




Fig. 2: Assembled Vent/Air System Kit Dimensions




Fig. 3: Optional Vent/Air System Components

SECTION II - Vent/Air System Installation

Vent/Air System Clearance Requirements

The vent/air system may maintain zero clearance to combustible & non-combustible materials.

Determine Termination Location

1. The maximum equivalent length of the concentric vent/air system should not exceed 100Ft (excluding the termination). For each 90° elbow in the system, the equivalent length is reduced by 10 feet. For each 45° elbow in the system, the equivalent length is reduced by 5 feet.
2. The installer must consider the following when determining the location of the vent/air system termination:
 - a. Locate the termination where flue vapors will not damage surrounding shrubs, plants or air conditioning equipment or be objectionable to the homeowner.
 - b. The flue products will form a noticeable plume as they condense in colder air. Avoid terminating in areas where the plume could obstruct window views.
 - c. Prevailing winds could cause freezing of flue condensation and a buildup of water/ice on surrounding plants, building surfaces or combustion air inlet.
 - d. Avoid locations of possible accidental contact of flue vapors with persons or pets.
 - e. Avoid locations where prevailing winds could affect the performance of the unit or cause recirculation of the flue gases, such as inside corners of buildings or near adjacent buildings or vertical surfaces, window wells, stairwells, alcoves, courtyards, or other recessed areas.
 - f. Do not terminate above any doors or windows; flue condensate could freeze causing ice formations.
 - g. Locate or guard the termination to prevent possible condensate damage to exterior finishes.

3. Maintain the following clearances to the termination:
 - a. At least 3 feet from adjacent walls
 - b. No closer than 3 feet below roof overhangs
 - c. At least 7 feet above any public walkways
 - d. At least 3 feet above any forced air intake (does not include the combustion air inlet) within 10 feet.
 - e. The termination must be at least 4 feet from any electric meters, gas meters, gas meter-regulators, relief valves or other equipment. Never terminate above or below any of these items within 4 feet horizontally.
 - f. Must maintain 12-inch clearances below and horizontally from doors and windows.





Fig. 4: Termination Clearances of Direct Vent Systems

- g. Air intake must terminate at least 12 inches above grade or anticipated snow line as shown in Fig. 5, page 5.
- h. Termination must not extend more than 9-1/2 inches beyond the exterior wall as shown in Fig. 5, page 5.




4. Horizontal or vertical runs of the vent/air system must be supported at every joint. The installer should use the Hanging Clamp, PSV-CLP01 or perforated metal strap hangers or equivalent to support the piping.
5. The vent/air system must terminate using the horizontal termination supplied in the kit.
6. The vent/air system must be pitched back to the boiler at minimum 5/8 inch per foot on any horizontal runs.

Boiler Vent /Air System Adapter

Install boiler vent/air system adapter over the boiler vent and air outlets. Secure the vent/air system adapter using the band clamps found on the vent and air adapters of the boiler.

NOTICE

Ensure Vent/Air System Adapter is properly oriented over the boiler adapters. The concentric outlet of the adapter should be installed toward the top left side of the boiler.



Vent/Air System Joint Assembly

1. When installing the vent system, the female end of the pipe or fitting should face up or away from the boiler.
2. Prior to assembly of any piping or fittings inspect and ensure the inner pipe gasket seal is present, undamaged and properly seated in the groove of the pipe.
3. Insert and rotate the male end of the inner pipe into the female end of the previous pipe section. It is recommend to moisten the gasket seal with clean water prior to assembly.


NOTICE

To aid in the assembly of the pipes and fittings use only clean water to moisten the gasket and the mating end of the pipe. Use a twisting motion as the pipe ends are pressed together.

4. Push the sections together firmly until the outer jacket bead of the new section has made contact with the edge of the female end of the previous section. When fully assembled, the outer female end of the previous section will overlap the male end by approximately 1".
5. Use 2 self-drilling screws provided to secure the outer sections together where they overlap. Install screws 90° apart from one another. No pre-drilling is required.

WARNING

Do not over tighten the self-drilling screws into the sections. Use a low torque screw drive to prevent stripping out the holes. If a hole becomes stripped due to over tightening, a larger diameter screw (length of screw must not exceed 1/2") or a short pop rivet may be used.



Note: Secure outer sections together where they overlap with 2 self-drilling screws provided, 90° apart using low torque setting of driver.

Fig. 7: Vent Joint Assembly

6. Seal the two components together by placing a clamp over the connection and pressing down on the clamp lever. The clamp should be centered over the connection and the edge of the clamp should cover the beads on the end of each component. If the clamp does not cover and lock onto the component jacket beads, ensure the components are fully pressed together and interlocked

WARNING

It is very important that the clamp be properly installed. Failure to properly connect the vent components could lead to vent failure and can result in death, serious injury or substantial property damage.

Termination Installation

1. Determine the termination location using the guidelines listed on page 4 and 5 and drill or cut a 6 inch hole.
2. Install the interior support plate on the inside wall using the screws provide in the kit.
3. Mount the termination fitting through the interior support plate from the exterior side of the wall. Ensure the air inlet holes of the termination fitting are facing down and that the fitting is mounted level.

NOTICE

To determine the appropriate length of the termination fitting, mount the exterior support plate temporarily prior to the installation of the interior support plate. Insert the termination fitting from the interior side of the wall through the exterior support plate. The termination fitting has a formed bead that limits the distance of penetration through the exterior support plate. The termination fitting should be measured and cut to length prior to mounting the support plates. For information on measuring and cutting the termination fitting, reference page 7.

4. Mount the exterior support plate around the termination on the outside wall. Ensure the support plate is flush to the formed end of the termination fitting and the fitting is mounted level.

NOTICE

The termination fitting must be installed level without pitch to either the boiler or away from boiler.

- The gaps between the outer pipe of the termination fitting and the support plates must be sealed with a high quality silicone caulk. Also apply the silicone caulk along the outer edge of the support plates sealing the plates to the wall.

Cutting Termination Fitting to Length

- Only the termination fitting can be cut to length if required.
- Add 3/4" to the required length and mark the end of the outer pipe.

NOTICE

Measure twice, cut once! Make sure to add 3/4" to the overall required length when cutting both pipes.

- Cut the pipes using an abrasive cutoff saw or hacksaw (minimum 32 teeth per inch). Make sure that the inner pipe remains centered in the outer pipe while cutting. It may be helpful to temporarily connect the vent section to be cut into another vent pipe to keep the center pipe centered while cutting.
- Mark the end of the outer pipe at the required length. The length of the outer pipe should be 3/4" less than the inner pipe.
- Cut through the outer pipe ONLY using a hacksaw (minimum 32 teeth per inch), or snips.
- File off any burrs or rough edges on both pipes. Clean off any dust or dirt.
- If the cutting process distorted the roundness of the pipes, carefully use your thumbs to correct the distortion.

WARNING

When cutting or correcting the shape of the outer pipe, WEAR GLOVES. The ends of the vent pipes can become very sharp when cut.

Adjustable Length Vent/Air System Pipe

WARNING

The component piping and fittings (excluding the termination fitting) are not design to be cut for custom lengths. Cutting the piping or fittings to length may compromise the vent seal cause potential vent failure or leakage of flue gas resulting in death, serious injury or substantial injury.

- An adjustable straight vent/air system pipe length is available for applications that require custom lengths.
- The adjustable length vent/air system pipe is adjustable from a minimum of 12" up to a maximum of 16.5".
- To adjust the length, firmly grab each end of the pipe and twist together to shorten or twist apart to lengthen.

Fire Stop Support Plate

The Fire Stop Support Plate must be used when the vent/air system piping passing through any floors, ceilings, enclosed chase or exterior walls. This plate can be used for vertical or horizontal penetrations.

1. Prepare a 6-inch round or square opening. Remove any insulation from the opening.
2. Secure the plate at the corners using the screws provided. For exterior wall penetrations, 2 plates are required. For interior wall/floor penetrations, 1 plate is required.
3. Install the concentric pipe through the plate. Secure the pipe to the Fire Stop Support Plate using only the self-drilling screws provided, through the plate tabs and into the concentric pipes outer jacket.

NOTICE

The Support Plate provided in the Concentric Vent/Air System Kit - PSVKIT03 does not contain tabs for securing the pipe to the plate, where the Fire Stop Support Plate does.

4. Seal around the support plate where attached to exterior of building and around pipe penetration, through the support plates with silicone sealant.

Multiple Vent/Air System Terminations

For multiple boiler vent/air system installations maintain a minimum of 12 inches from centerlines as shown in Fig. 8.




Fig. 8: Multiple Vent/Air System Terminations

SECTION III - Maintenance Procedures

Inspect Vent/Air System

Visually inspect the vent/air system annually for blockage, deterioration or leakage. Immediately repair any joints that show signs of deterioration or leakage with the boiler turned off.

WARNING

Failure to inspect the vent/air system and have any conditions repaired can result in severe personal injury or death.

Additional quality water heating equipment available from Triangle Tube

Brazed Plate Heat Exchangers



- For domestic water, snow melting, radiant floor, refrigeration
- Plates made of stainless steel, with a 99.9 % copper and brazed, ensuring a high resistance to corrosion
- Self cleaning and self descaling
- Computerized sizing available from Triangle Tube/Phase III
- Available in capacities from 25,000 BTU/hr to 5,000,000 BTU/hr

Prestige Condensing Wall Mounted Boiler



- 95% AFUE - Energy Star Certified
- Fully modulating
- Natural gas or propane
- Stainless Steel Construction
- Direct vent with standard schedule 40 PVC
- Outdoor Reset
- Low Nox

SMART Indirect Fired Water Heaters



- Exclusive " Tank-in-Tank" design
- Stainless steel construction
- Available in 8 sizes and 2 models
- Limited LIFETIME residential warranty
- Self cleaning/self descaling design

Maxi-flo Pool and Spa Heat Exchangers



- Constructed of high quality corrosion resistant stainless steel (AISI 316)
- Specially designed built-in flow restrictor to assure maximum heat exchange
- Compact and light weight
- Available in 5 sizes that can accommodate any size pool or spa



Freeway Center - 1 Triangle Lane
Blackwood, NJ 08012
Tel: (856) 228 8881 - Fax: (856) 228 3584
E-mail: Sales@triangletube.com

