



## OWNER'S MANUAL

# HYPER HEAT MINI-SPLIT SYSTEM

---



---

MODELS: 3PAMSHH09-UVW, 3PAMSHH09-SZO, 3PAMSHH12-UVW, 3PAMSHH12-SZO,  
3PAMSHH18-UVW, 3PAMSHH18-SZO, 3PAMSHH24-UVW, 3PAMSHH24-SZO

# TABLE OF CONTENTS

<b>SAFETY PRECAUTIONS .....</b>	<b>5</b>
---------------------------------	----------

## **OWNER'S MANUAL**

<b>UNIT SPECIFICATIONS AND FEATURES .....</b>	<b>8</b>
Indoor unit display .....	8
Operating temperature.....	9
Other Features.....	10
Setting Angle of Airflow .....	11
Manual Operation (without remote).....	11
<b>CARE AND MAINTENANCE.....</b>	<b>12</b>
Cleaning Your Indoor Unit.....	12
Cleaning Your Air Filter .....	12
Air Filter Reminders.....	13
Maintenance – Long Periods of Non-Use.....	13
<b>TROUBLESHOOTING.....</b>	<b>14</b>
<b>ACCESSORIES .....</b>	<b>17</b>

## **INSTALLATION MANUAL**

<b>INSTALLATION SUMMARY - INDOOR UNIT.....</b>	<b>18</b>
<b>UNIT PARTS .....</b>	<b>19</b>
<b>INDOOR UNIT INSTALLATION .....</b>	<b>20</b>
Step 1: Select installation location .....	20
Step 2: Attach mounting plate to wall.....	20
Step 3: Drill wall hole for connective piping.....	21
Step 4: Prepare refrigerant piping.....	21
Step 5: Connect drain hose.....	22
Cable Types.....	23
Step 7: Wrap piping and cables .....	24
Step 8: Mount indoor unit.....	25
<b>OUTDOOR UNIT INSTALLATION .....</b>	<b>26</b>
Step 1: Select installation location .....	26
<b>SPECIAL CONSIDERATIONS FOR EXTREME WEATHER .....</b>	<b>26</b>
Step 2: Install drain joint (Heat pump unit only).....	27
Step 3: Anchor outdoor unit.....	27
Step 4: Connect signal and power cables.....	28

### **IMPORTANT NOTE:**

Read this manual and SAFETY MANUAL(if any) carefully before installing or operating your new air conditioning unit. Make sure to save this manual for future reference.

Please check the applicable models, technical data, F-GAS (if any) and manufacturer information from the "Owner's Manual - Product Fiche" in the packaging of the outdoor unit (European Union products only) or in the packaging of the indoor unit (model dependent)

## INSTALLATION MANUAL CONTINUED

<b>REFRIGERANT PIPING CONNECTION .....</b>	<b>30</b>
Note on Pipe Length.....	30
Connection Instructions – Refrigerant Piping.....	30
<i>Step 1: Cut pipes</i> .....	30
<i>Step 2: Remove burrs</i> .....	31
<i>Step 3: Flare pipe ends</i> .....	31
<i>Step 4: Connect pipes</i> .....	31
Instructions for Connecting Piping to Indoor Unit.....	31
Instructions for Connecting Piping to Outdoor Unit.....	32
<b>AIR EVACUATION .....</b>	<b>33</b>
Evacuation Instructions .....	33
Note on Adding Refrigerant.....	34
<b>ELECTRICAL AND GAS LEAK CHECKS .....</b>	<b>35</b>
<b>TEST RUN .....</b>	<b>36</b>
<b>PACKING AND UNPACKING THE UNIT.....</b>	<b>37</b>

## Read Safety Precautions Before Operation and Installation

Incorrect installation due to ignoring instructions can cause serious damage or injury.

The seriousness of potential damage or injuries is classified as either a **WARNING** or **CAUTION**.

### **WARNING**

This symbol indicates the possibility of personnel injury or loss of life.

### **WARNING**

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision (European Union countries).

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

### **CAUTION**

This symbol indicates the possibility of property damage or serious consequences.

### **PRODUCT USE WARNINGS**

- If an abnormal situation arises (like a burning smell), immediately turn off the unit and disconnect the power. Call your dealer for instructions to avoid electric shock, fire or injury.
- **Do not** insert fingers, rods or other objects into the air inlet or outlet. This may cause injury, since the fan may be rotating at high speeds.
- **Do not** use flammable sprays such as hair spray, lacquer or paint near the unit. This may cause fire or combustion.
- **Do not** operate the air conditioner in places near or around combustible gases. Emitted gas may collect around the unit and cause explosion.
- **Do not** operate your air conditioner in a wet room such as a bathroom or laundry room. Too much exposure to water can cause electrical components to short circuit.
- **Do not** expose your body directly to cool air for a prolonged period of time.
- **Do not** allow children to play with the air conditioner. Children must be supervised around the unit at all times.
- If the air conditioner is used together with burners or other heating devices, thoroughly ventilate the room to avoid oxygen deficiency.
- In certain functional environments, such as kitchens, server rooms, etc., the use of specially designed air-conditioning units is highly recommended.

**⚠ CAUTION**

- Turn off the air conditioner and disconnect the power if you are not going to use it for a long time.
- Turn off and unplug the unit during storms.
- Make sure that water condensation can drain unhindered from the unit.
- **Do not** operate the air conditioner with wet hands. This may cause electric shock.
- **Do not** use device for any other purpose than its intended use.
- **Do not** climb onto or place objects on top of the outdoor unit.
- **Do not** allow the air conditioner to operate for long periods of time with doors or windows open, or if the humidity is very high.

**TAKE NOTE OF FUSE SPECIFICATIONS**

The air conditioner's circuit board (PCB) is designed with a fuse to provide over current protection.

The specifications of the fuse are printed on the circuit board, such as :

T3.15AL/250VAC, T5AL/250VAC, T3.15A/250VAC, T5A/250VAC, T20A/250VAC, T30A/250VAC, etc.

**⚠ CLEANING AND MAINTENANCE WARNINGS**

- Turn off the device and disconnect the power before cleaning. Failure to do so can cause electrical shock.
- Do not clean the air conditioner with excessive amounts of water.
- Do not clean the air conditioner with combustible cleaning agents. Combustible cleaning agents can cause fire or deformation.

**⚠ ELECTRICAL WARNINGS**

- Only use the specified power cord. If the power cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Keep power plug clean. Remove any dust or grime that accumulates on or around the plug. Dirty plugs can cause fire or electric shock.
- Do not pull power cord to unplug unit. Hold the plug firmly and pull it from the outlet. Pulling directly on the cord can damage it, which can lead to fire or electric shock.
- Do not modify the length of the power supply cord or use an extension cord to power the unit.
- Do not share the electrical outlet with other appliances. Improper or insufficient power supply can cause fire or electrical shock.
- The product must be properly grounded at the time of installation, or electrical shock may occur.
- For all electrical work, follow all local and national wiring standards, regulations, and the Installation Manual. Connect cables tightly, and clamp them securely to prevent external forces from damaging the terminal. Improper electrical connections can overheat and cause fire, and may also cause shock. All electrical connections must be made according to the Electrical Connection Diagram located on the panels of the indoor and outdoor units.
- All wiring must be properly arranged to ensure that the control board cover can close properly. If the control board cover is not closed properly, it can lead to corrosion and cause the connection points on the terminal to heat up, catch fire, or cause electrical shock.
- If connecting power to fixed wiring, an all-pole disconnection device which has at least 3mm clearances in all poles, and have a leakage current that may exceed 10mA, the residual current device (RCD) having a rated residual operating current not exceeding 30mA, and disconnection must be incorporated in the fixed wiring in accordance with the wiring rules.

**⚠ PRODUCT INSTALLATION WARNINGS**

- 1 Installation must be performed by an authorized dealer or specialist. Defective installation can cause water leakage, electrical shock, or fire.
- 2 Installation must be performed according to the installation instructions. Improper installation can cause water leakage, electrical shock, or fire. (In North America, installation must be performed in accordance with the requirement of NEC and CEC by authorized personnel only.)
- 3 Contact an authorized service technician for repair or maintenance of this unit. This appliance shall be installed in accordance with national wiring regulations.
- 4 Only use the included accessories, parts, and specified parts for installation. Using non-standard parts can cause water leakage, electrical shock, fire, and can cause the unit to fail.
- 5 Install the unit in a firm location that can support the unit's weight. If the chosen location cannot support the unit's weight, or the installation is not done properly, the unit may drop and cause serious injury and damage.
- 6 Install drainage piping according to the instructions in this manual. Improper drainage may cause water damage to your home and property.
- 7 For units that have an auxiliary electric heater, do not install the unit within 1 meter (3 feet) of any combustible materials
- 8 Do not install the unit in a location that may be exposed to combustible gas leaks. If combustible gas accumulates around the unit, it may cause fire.

- 9 Do not turn on the power until all work has been completed.
- 10 When moving or relocating the air conditioner, consult experienced service technicians for disconnection and re-installation of the unit.
- 11 How to install the appliance to its support, please read the information for details in "indoor unit installation" and "outdoor unit installation" sections.

**NOTE ABOUT FLUORINATED GASSES**

(NOT APPLICABLE TO THE UNIT USING R290 REFRIGERANT)


- 1 This air-conditioning unit contains fluorinated greenhouse gases. For specific information on the type of gas and the amount, please refer to the relevant label on the unit itself or the "Owner's Manual - Product Fiche" in the packaging of the outdoor unit. (European Union products only).
- 2 Installation, service, maintenance and repair of this unit must be performed by a certified technician.
- 3 Product uninstallation and recycling must be performed by a certified technician
- 4 For equipment that contains fluorinated greenhouse gases in quantities of 5 tonnes of CO<sub>2</sub> equivalent or more, but of less than 50 tonnes of CO<sub>2</sub> equivalent, If the system has a leak- detection system installed, it must be checked for leaks at least every 24 months.
- 5 When the unit is checked for leaks, proper record-keeping of all checks is strongly recommended.

# UNIT SPECIFICATIONS AND FEATURES

## INDOOR UNIT DISPLAY

**NOTE:** Different models have different front panels and display windows. Not all the display codes describing below are available for the air conditioner you purchased. Please check the indoor display window of the unit you purchased.

Illustrations in this manual are for explanatory purposes. The actual shape of your indoor unit may be slightly different. The actual shape shall prevail.



**"fresh"** when Fresh and UV-C lamp (if any) feature is activated (not available)

**"defrost"** when defrost feature is activated.

**"run"** when the unit is on.

**"timer"** when TIMER is set.

**"📶"** when Wireless Control feature is activated (not available)

**"88"** Displays temperature, operation feature and error codes:

**"01"** for 3 seconds when:

- TIMER ON is set (if the unit is OFF, **"01"** remains on when TIMER ON is set)
- FRESH, UV-C lamp, SWING, TURBO, ECO, or SILENCE feature is turned on

**"0F"** for 3 seconds when:

- TIMER OFF is set
- FRESH, UV-C lamp, SWING, TURBO, ECO, or SILENCE feature is turned off

**"dF"** when defrosting

**"FP"** when 8 C heating feature is turned on (some units)

**"CL"** when Active Clean feature is turned on (For Inverter split type) when unit is self-cleaning (For Fixed-speed type)

### DISPLAY CODE MEANINGS

# UNIT SPECIFICATIONS AND FEATURES

(Continued)

## OPERATING TEMPERATURE

When your air conditioner is used outside of the following temperature ranges, certain safety protection features may activate and cause the unit to disable.

### INVERTER SPLIT TYPE

	COOL mode	HEAT mode	DRY mode
<b>Room Temperature</b>	60°F - 90°F (16°C - 32°C)	32°F - 86°F (0°C - 30°C)	50°F - 90°F (10°C - 32°C)
<b>Outdoor Temperature</b>	32°F - 122°F (0°C - 50°C)	5°F - 75°F (-15°C - 24°C)	32°F - 122°F (0°C - 50°C)
	5°F - 122°F (-15°C - 50°C) (For models with low-temp cooling systems.)		

### FIXED-SPEED TYPE

	COOL mode	HEAT mode	DRY mode
<b>Room Temperature</b>	60°F - 90°F (16°C - 32°C)	32°F - 86°F (0°C - 30°C)	50°F - 90°F (10°C - 32°C)
<b>Outdoor Temperature</b>	64°F - 109°F (18°C - 43°C)	19°F - 75°F (-7°C - 24°C)	52°F - 109°F (11°C - 43°C)
	19°F - 109°F (-7°C - 43°C) (For models with low-temp cooling systems.)		64°F - 109°F (18°C - 43°C)

**NOTE:** Room relative humidity less than 80%. If the air conditioner operates in excess of this figure, the surface of the air conditioner may attract condensation. Please sets the vertical airflow louver to its maximum angle (vertically to the floor), and set HIGH fan mode.

### To further optimize the performance of your unit, do the following:

- Keep doors and windows closed.
- Limit energy usage by using TIMER ON and TIMER OFF functions.
- Do not block air inlets or outlets.
- Regularly inspect and clean air filters.



A guide on using the infrared remote is not included in this literature package. Not all the functions are available for the air conditioner, please check the indoor display and remote control of the unit you purchased.

## OTHER FEATURES

### • AUTO-RESTART

If the unit loses power, it will automatically restart with the prior settings once power has been restored.

### • LOUVER ANGLE MEMORY

When turning on your unit, the louver will automatically resume its former angle.

### • ACTIVE CLEAN FUNCTION

— The Active Clean Technology washes away dust when it adheres to the heat exchanger by automatically freezing and then rapidly thawing the frost. A “pi-pi” sound will be heard. The Active clean operation is used to produce more condensed water to improve the cleaning effect, and the cold air will blow out. After cleaning, the internal wind wheel then keeps operating with hot air to blow-dry the evaporator, thus keeping the inside clean.

— When this function is turned on, the indoor unit display window appears “CL”, after 20 to 130 minutes, the unit will turn off automatically and cancel Active Clean function.

— For some units, the system will start high temperature cleaning process, and the temperature of air outlet is very high. Please keep away from it. And this would lead to the rising of the room temperature.

### • BREEZE AWAY


This feature avoids direct airflow blowing on the body and make you feel indulging in silky coolness.

### • REFRIGERANT LEAKAGE DETECTION

The indoor unit will automatically display “ELOC” or flash LEDs when it detects refrigerant leakage.

### • SLEEP OPERATION

The SLEEP function is used to decrease energy use while you sleep (and don't need the same temperature settings to stay comfortable). This function can only be activated via remote control. And the Sleep function is not available in FAN or DRY mode. Press the **SLEEP** button when you are ready to go to sleep. When in COOL mode, the unit will increase the temperature by 2°F (1°C) after 1 hour, and will increase an additional 2°F (1°C) after another hour. When in HEAT mode, the unit will decrease the temperature by 2°F (1°C) after 1 hour, and will decrease an additional 2°F (1°C) after another hour. The sleep feature will stop after 8 hours and the system will keep running with final situation.



**NOTE:** For multi-split air conditioners, the following functions are not available:

Active clean function, Silence feature, Breeze away function, Refrigerant leakage detection function and Eco feature.

## SETTING ANGLE OF AIRFLOW

### Setting vertical angle of airflow

While the unit is on, use the **SWING/DIRECT** button on remote control to set the direction (vertical angle) of airflow. Please refer to the Remote Control Manual for details.

#### NOTE ON LOUVER ANGLES:

When using COOL or DRY mode, do not set louver at too vertical an angle for long periods of time. This can cause water to condense on the louver blade, which will drop on your floor or furnishings.

When using COOL or HEAT mode, setting the louver at too small an angle can reduce the performance of the unit due to restricted airflow.

**NOTE:** According to the relative standards requirement, please sets the vertical airflow louver to its maximum angle under heating capacity test.

### Setting horizontal angle of airflow

The horizontal angle of the airflow must be set manually. Grip the deflector rod (See Fig.B) and manually adjust it to your preferred direction.


## MANUAL OPERATION (WITHOUT REMOTE)

**CAUTION** The manual button is intended for testing purposes and emergency operation only. Please do not use this function unless the remote control is lost and it is absolutely necessary. To restore regular operation, use the remote control to activate the unit. Unit must be turned off before manual operation.

To operate your unit manually:

- 1 Open the front panel of the indoor unit.
- 2 Locate the **MANUAL CONTROL button** on the right-hand side of the unit.
- 3 Press the **MANUAL CONTROL button** one time to activate FORCED AUTO mode.

- 4 Press the **MANUAL CONTROL button** again to activate FORCED COOLING mode.
- 5 Press the **MANUAL CONTROL button** a third time to turn the unit off.
- 6 Close the front panel.



**NOTE:** Do not move vertical louver by hand. This will cause the louver to become out of sync. If this occurs, turn off the unit and shut off main power supply it for 3 minutes, then restart the unit. This will reset the louver. **Fig. A.**

## CAUTION

Do not put your fingers in or near the blower and suction side of the unit. The high-speed fan inside the unit may cause injury.





Fig. B



## CLEANING YOUR INDOOR UNIT

### BEFORE CLEANING OR MAINTENANCE

**ALWAYS TURN OFF YOUR AIR CONDITIONER SYSTEM AND DISCONNECT ITS POWER SUPPLY BEFORE CLEANING OR MAINTENANCE.**

### CAUTION

Only use a soft, dry cloth to wipe the unit clean. If the unit is especially dirty, you can use a cloth soaked in warm water to wipe it clean.





- **Do not** use chemicals or chemically treated cloths to clean the unit.
- **Do not** use benzene, paint thinner, polishing powder or other solvents to clean the unit. They can cause the plastic surface to crack or deform.
- **Do not** use water hotter than 104°F (40°C) to clean the front panel. This can cause the panel to deform or become discolored.

## CLEANING YOUR AIR FILTER

A clogged air conditioner can reduce the cooling efficiency of your unit, and can also be bad for your health. Make sure to clean the filter once every two weeks.

- 1 Lift the front panel of the indoor unit.
- 2 First press the tab on the end of filter to loosen the buckle, lift it up, then pull it towards yourself.
- 3 Now pull the filter out.
- 4 If your filter has a small air freshening filter, unclip it from the larger filter. Clean this air freshening filter with a hand-held vacuum.
- 5 Clean the large air filter with warm, soapy water. Be sure to use a mild detergent.
- 6 Rinse the filter with fresh water, then shake off excess water.

- 7 Dry it in a cool, dry place, and refrain from exposing it to direct sunlight.
- 8 When dry, re-clip the air freshening filter to the larger filter, then slide it back into the indoor unit.
- 9 Close the front panel of the indoor unit.



### CAUTION

Do not touch air freshening (Plasma) filter for at least 10 minutes after turning off the unit.

### CAUTION

- Before changing the filter or cleaning, turn off the unit and disconnect its power supply.
- When removing filter, do not touch metal parts in the unit. The sharp metal edges can cut you.
- Do not use water to clean the inside of the indoor unit. This can destroy insulation and cause electrical shock.
- Do not expose filter to direct sunlight when drying. This can shrink the filter.

## AIR FILTER REMINDERS

### AIR FILTER CLEANING REMINDER

After 240 hours of use, the display window on the indoor unit will flash "CL." This is a reminder to clean your filter. After 15 seconds, the unit will revert to its previous display.

To reset the reminder, press the **LED** button on your remote control 4 times, or press the **MANUAL CONTROL** button 3 times. If you don't reset the reminder, the "CL" indicator will flash again when you restart the unit.

### AIR FILTER REPLACEMENT REMINDER

After 2,880 hours of use, the display window on the indoor unit will flash "nF." This is a reminder to replace your filter. After 15 seconds, the unit will revert to its previous display.


To reset the reminder, press the **LED** button on your remote control 4 times, or press the **MANUAL CONTROL** button 3 times. If you don't reset the reminder, the "nF" indicator will flash again when you restart the unit.

### CAUTION


- Any maintenance and cleaning of outdoor unit should be performed by an authorized dealer or a licensed service provider.
- Any unit repairs should be performed by an authorized dealer or a licensed service provider.

## MAINTENANCE – LONG PERIODS OF NON-USE


If you plan not to use your air conditioner for an extended period of time, do the following:




Clean all filters



Turn on FAN function until unit dries out completely




Turn off the unit and disconnect the power




Remove batteries from remote control

## MAINTENANCE – PRE-SEASON INSPECTION

After long periods of non-use, or before periods of frequent use, do the following:




Check for damaged wires




Clean all filters



Check for leaks



Replace batteries



Make sure nothing is blocking all air inlets and outlets

# TROUBLESHOOTING

## ⚠ SAFETY PRECAUTIONS

If ANY of the following conditions occurs, turn off your unit immediately!

- The power cord is damaged or abnormally warm
- You smell a burning odor
- The unit emits loud or abnormal sounds
- A power fuse blows or the circuit breaker frequently trips
- Water or other objects fall into or out of the unit

**DO NOT ATTEMPT TO FIX THESE YOURSELF! CONTACT AN AUTHORIZED SERVICE PROVIDER IMMEDIATELY!**

## COMMON ISSUES

The following problems are not a malfunction and in most situations will not require repairs.

Issue	Possible Causes
<b>Unit does not turn on when pressing ON/OFF button</b>	The Unit has a 3-minute protection feature that prevents the unit from overloading. The unit cannot be restarted within three minutes of being turned off.
<b>The unit changes from COOL/HEAT mode to FAN mode</b>	The unit may change its setting to prevent frost from forming on the unit. Once the temperature increases, the unit will start operating in the previously selected mode again.
	The set temperature has been reached, at which point the unit turns off the compressor. The unit will continue operating when the temperature fluctuates again.
<b>The indoor unit emits white mist</b>	In humid regions, a large temperature difference between the room's air and the conditioned air can cause white mist.
<b>Both the indoor and outdoor units emit white mist</b>	When the unit restarts in HEAT mode after defrosting, white mist may be emitted due to moisture generated from the defrosting process.
<b>The indoor unit makes noises</b>	A rushing air sound may occur when the louver resets its position.
	A squeaking sound may occur after running the unit in HEAT mode due to expansion and contraction of the unit's plastic parts.
<b>Both the indoor unit and outdoor unit make noises</b>	Low hissing sound during operation: This is normal and is caused by refrigerant gas flowing through both indoor and outdoor units.
	Low hissing sound when the system starts, has just stopped running, or is defrosting: This noise is normal and is caused by the refrigerant gas stopping or changing direction.
	Squeaking sound: Normal expansion and contraction of plastic and metal parts caused by temperature changes during operation can cause squeaking noises.

# TROUBLESHOOTING

(Continued)

Issue	Possible Causes
<b>The outdoor unit makes noises</b>	The unit will make different sounds based on its current operating mode.
<b>Dust is emitted from either the indoor or outdoor unit</b>	The unit may accumulate dust during extended periods of non-use, which will be emitted when the unit is turned on. This can be mitigated by covering the unit during long periods of inactivity.
<b>The unit emits a bad odor</b>	The unit may absorb odors from the environment (such as furniture, cooking, cigarettes, etc.) which will be emitted during operations.
	The unit's filters have become moldy and should be cleaned.
<b>The fan of the outdoor unit does not operate</b>	During operation, the fan speed is controlled to optimize product operation.
<b>Operation is erratic, unpredictable, or unit is unresponsive</b>	Interference from cell phone towers and remote boosters may cause the unit to malfunction.
	In this case, try the following: <ul style="list-style-type: none"> <li>• Disconnect the power, then reconnect.</li> <li>• Press ON/OFF button on remote control to restart operation.</li> </ul>

**NOTE:** If problem persists, contact a local dealer or your nearest customer service center. Provide them with a detailed description of the unit malfunction as well as your model number.

## TROUBLESHOOTING

When troubles occur, please check the following points before contacting a repair company.

Problem	Possible Causes	Solution
<b>Poor cooling performance</b>	Temperature setting may be higher than ambient room temperature	Lower the temperature setting
	The heat exchanger on the indoor or outdoor unit is dirty	Clean the affected heat exchanger
	The air filter is dirty	Remove the filter and clean it according to instructions
	The air inlet or outlet of either unit is blocked	Turn the unit off, remove the obstruction and turn it back on
	Doors and windows are open	Make sure that all doors and windows are closed while operating the unit
	Excessive heat is generated by sunlight	Close windows and curtains during periods of high heat or bright sunshine
	Too many sources of heat in the room (people, computers, electronics, etc.)	Reduce amount of heat sources
	Low refrigerant due to leak or long-term use	Check for leaks, re-seal if necessary and top off refrigerant
	SILENCE function is activated	SILENCE function can lower product performance by reducing operating frequency. Turn off SILENCE function.



# TROUBLESHOOTING












(Continued)

Problem	Possible Causes	Solution
<b>The unit is not working</b>	Power failure	Wait for the power to be restored
	The power is turned off	Turn on the power
	The fuse is burned out	Replace the fuse
	Remote control batteries are dead	Replace batteries
	The Unit's 3-minute protection has been activated	Wait three minutes after restarting the unit
	Timer is activated	Turn timer off
<b>The unit starts and stops frequently</b>	There's too much or too little refrigerant in the system	Check for leaks and recharge the system with refrigerant.
	Incompressible gas or moisture has entered the system.	Evacuate and recharge the system with refrigerant
	The compressor is broken	Replace the compressor
	The voltage is too high or too low	Install a manostat to regulate the voltage
<b>Poor heating performance</b>	The outdoor temperature is extremely low	Use auxiliary heating device
	Cold air is entering through doors and windows	Make sure that all doors and windows are closed during use
	Low refrigerant due to leak or long-term use	Check for leaks, re-seal if necessary and top off refrigerant
<b>Indicator lamps continue flashing</b>	The unit may stop operation or continue to run safely. If the indicator lamps continue to flash or error codes appear, wait for about 10 minutes. The problem may resolve itself.	
<b>Error code appears and begins with the letters as the following in the window display of indoor unit:</b>	If not, disconnect the power, then connect it again. Turn the unit on. If the problem persists, disconnect the power and contact your nearest customer service center.	
	<ul style="list-style-type: none"> <li>• <b>E(x), P(x), F(x)</b></li> <li>• <b>EH(xx), EL(xx), EC(xx)</b></li> <li>• <b>PH(xx), PL(xx), PC(xx)</b></li> </ul>	

**NOTE:** If your problem persists after performing the checks and diagnostics above, turn off your unit immediately and contact an authorized service center.


# ACCESSORIES

The air conditioning system comes with the following accessories. Use all of the installation parts and accessories to install the air conditioner. Improper installation may result in water leakage, electrical shock and fire, or cause the equipment to fail. The items are not included with the air conditioner must be purchased separately.

Name of Accessories	Q'ty (pc)	Shape	Name of Accessories	Q'ty (pc)	Shape
<b>Manual</b>	2~3		<b>Remote control</b>	1	
<b>Drain joint (for cooling &amp; heating models)</b>	1		<b>Battery</b>	2	
<b>Seal (for cooling &amp; heating models)</b>	1		<b>Remote control holder</b>	1	
<b>Mounting plate</b>	1		<b>Fixing screw for remote control holder</b>	2	
<b>Anchor</b>	5		<b>Small Filter</b> (Need to be installed on the back of main air filter by the authorized technician while installing the machine)	1~2 (depending on models)	
<b>Mounting plate fixing screw</b>	5				


Name	Shape	Quantity (PC)
<b>Connecting pipe assembly</b>	<b>Liquid side</b>	Φ 6.35 (1/4 in)
		Φ 9.52 (3/8in)
	<b>Gas side</b>	Φ 9.52 (3/8in)
		Φ 12.7 (1/2in)
		Φ 16 (5/8in)
	Φ 19 (3/4in)	
		Parts you must purchase separately. Consult the dealer about the proper pipe size of the unit you purchased.

# INSTALLATION SUMMARY - INDOOR UNIT



# UNIT PARTS

**NOTE:** The installation must be performed in accordance with the requirement of local and national standards. The installation may be slightly different in different areas.



- ① Wall Mounting Plate
- ② Front Panel
- ③ Louver
- ④ Functional Filter (on back of main filter - some units)
- ⑤ Drainage Pipe
- ⑥ Signal Cable
- ⑦ Refrigerant Piping
- ⑧ Remote Control
- ⑨ Remote Control Holder
- ⑩ Outdoor Unit Power Cable

**NOTE ON ILLUSTRATIONS:** Illustrations in this manual are for explanatory purposes. The actual shape of your indoor unit may be slightly different. The actual shape shall prevail.

## INSTALLATION INSTRUCTIONS – INDOOR UNIT

### PRIOR TO INSTALLATION

Before installing the indoor unit, refer to the label on the product box to make sure that the model number of the indoor unit matches the model number of the outdoor unit.

### STEP 1: SELECT INSTALLATION LOCATION

Before installing the indoor unit, you must choose an appropriate location. The following are standards that will help you choose an appropriate location for the unit.

#### Proper installation locations meet the following standards:

- ☑ Good air circulation
- ☑ Convenient drainage
- ☑ Noise from the unit will not disturb other people
- ☑ Firm and solid — the location will not vibrate
- ☑ Strong enough to support the weight of the unit
- ☑ A location at least one meter from all other electrical devices (e.g., TV, radio, computer)


#### DO NOT install unit in the following locations:

- ⊗ Near any source of heat, steam, or combustible gas
- ⊗ Near flammable items such as curtains or clothing
- ⊗ Near any obstacle that might block air circulation
- ⊗ Near the doorway
- ⊗ In a location subject to direct sunlight

### NOTE ABOUT WALL HOLE:

If there is no fixed refrigerant piping: While choosing a location, be aware that you should leave ample room for a wall hole (see **Drill wall hole for connective piping** step) for the signal cable and refrigerant piping that connect the indoor and outdoor units. The default position for all piping is the right side of the indoor unit (while facing the unit). However, the unit can accommodate piping to both the left and right.


#### Refer to the following diagram to ensure proper distance from walls and ceiling:



### STEP 2: ATTACH MOUNTING PLATE TO WALL

The mounting plate is the device on which you will mount the indoor unit.

- Remove the screw that attaches the mounting plate to the back of the indoor unit.



- Secure the mounting plate to the wall with the screws provided. Make sure that mounting plate is flat against the wall.

### NOTE FOR CONCRETE OR BRICK WALLS:

If the wall is made of brick, concrete, or similar material, drill 5mm-diameter (0.2in-diameter) holes in the wall and insert the sleeve anchors provided. Then secure the mounting plate to the wall by tightening the screws directly into the clip anchors.

### STEP 3: DRILL WALL HOLE FOR CONNECTIVE PIPING


Determine the location of the wall hole based on the position of the mounting plate. Refer to Mounting Plate Dimensions.

Using a 2.5in (65mm) or 3.54in (90mm) (depending on models) core drill, drill a hole in the wall. Make sure that the hole is drilled at a slight downward angle, so that the outdoor end of the hole is lower than the indoor end by about 0.2-0.275in (5mm to 7mm). This will ensure proper water drainage.

Place the protective wall cuff in the hole. This protects the edges of the hole and will help seal it when you finish the installation process.

### CAUTION




When drilling the wall hole, make sure to avoid wires, plumbing, and other sensitive components.



### MOUNTING PLATE DIMENSIONS:

Different models have different mounting plates. For the different customization requirements, the shape of the mounting plate and the dimensions of the indoor unit may be slightly different.

Correct orientation of Mounting Plate




**NOTE:** When the gas side connective pipe is  $\Phi$  5/8in (16mm) or more, the wall hole should be 3.54in (90mm).

### STEP 4: PREPARE REFRIGERANT PIPING

The refrigerant piping is inside an insulating sleeve attached to the back of the unit. You must prepare the piping before passing it through the hole in the wall.


- 1 Based on the position of the wall hole relative to the mounting plate, choose the side from which the piping will exit the unit.
- 2 If the wall hole is behind the unit, keep the knock-out panel in place. If the wall hole is to the side of the indoor unit, remove the plastic knock-out panel from that side of the unit. This will create a slot through which your piping can exit the unit. Use needle nose pliers if the plastic panel is too difficult to remove by hand.



- 3** If existing connective piping is already embedded in the wall, proceed directly to the **Connect Drain Hose** step. If there is no embedded piping, connect the indoor unit's refrigerant piping to the connective piping that will join the indoor and outdoor units. Refer to the **Refrigerant Piping Connection** section of this manual for detailed instructions.

### NOTE ON PIPING ANGLE:

Refrigerant piping can exit the indoor unit from four different angles: Left-hand side, Right-hand side, Left rear, Right rear.



### CAUTION

Be extremely careful not to dent or damage the piping while bending them away from the unit. Any dents in the piping will affect the unit's performance.


### STEP 5: CONNECT DRAIN HOSE

The refrigerant piping is inside an insulating sleeve. By default, the drain hose is attached to the left-hand side of unit (when you're facing the back of the unit). However, it can also be attached to the right-hand side. To ensure proper drainage, attach the drain hose on the same side that your refrigerant piping exits the unit. Attach drain hose extension (purchased separately) to the end of drain hose.


- Wrap the connection point firmly with Duct tape to ensure a good seal and to prevent leaks.
- For the portion of the drain hose that will remain indoors, wrap it with foam pipe insulation to prevent condensation.
- Remove the air filter and pour a small amount of water into the drain pan to make sure that water flows from the unit smoothly.

### NOTE ON DRAIN HOSE PLACEMENT:

Make sure to arrange the drain hose according to the following figures.



### PLUG THE UNUSED DRAIN HOLE



### BEFORE PERFORMING ANY ELECTRICAL WORK, READ THESE REGULATIONS

- 1** All wiring must comply with local and national electrical codes, regulations and must be installed by a licensed electrician.
- 2** All electrical connections must be made according to the Electrical Connection Diagram located on the panels of the indoor and outdoor units.

- 3** If there is a serious safety issue with the power supply, stop work immediately. Explain your reasoning to the client, and refuse to install the unit until the safety issue is properly resolved.
- 4** Power voltage should be within 90-110% of rated voltage. Insufficient power supply can cause malfunction, electrical shock, or fire.
- 5** If connecting power to fixed wiring, a surge protector and main power switch should be installed.
- 6** If connecting power to fixed wiring, a switch or circuit breaker that disconnects all poles and has a contact separation of at least 1/8 in (3mm) must be incorporated in the fixed wiring. The qualified technician must use an approved circuit breaker or switch.
- 7** Only connect the unit to an individual branch circuit outlet. Do not connect another appliance to that outlet.
- 8** Make sure to properly ground the air conditioner.
- 9** Every wire must be firmly connected. Loose wiring can cause the terminal to overheat, resulting in product malfunction and possible fire.
- 10** Do not let wires touch or rest against refrigerant tubing, the compressor, or any moving parts within the unit.
- 11** If the unit has an auxiliary electric heater, it must be installed at least 1 meter (40 in) away from any combustible materials
- 12** To avoid getting an electric shock, never touch the electrical components soon after the power supply has been turned off. After turning off the power, always wait 10 minutes or more before you touch the electrical components.

### WARNING

**BEFORE PERFORMING ANY ELECTRICAL OR WIRING WORK, TURN OFF THE MAIN POWER TO THE SYSTEM.**

### STEP 6: CONNECT SIGNAL AND POWER CABLES

The signal cable enables communication between the indoor and outdoor units. You must first choose the right cable size before preparing it for connection.

### CABLE TYPES

- **Signal Cable:** H07RN-F(14-4 AWG)

**NOTE:** In North America, choose the outdoor power cable type according to the local electrical codes and regulations.

### CHOOSE THE RIGHT CABLE SIZE


The size of the power supply cable, signal cable, fuse, and switch needed is determined by the maximum current of the unit. The maximum current is indicated on the nameplate located on the side panel of the unit.

**NOTE:** In North America, please choose the right cable size according to the Minimum Circuit Ampacity indicated on the nameplate of the unit.


### WARNING

**ALL WIRING MUST BE PERFORMED STRICTLY IN ACCORDANCE WITH THE WIRING DIAGRAM LOCATED ON THE BACK OF THE INDOOR UNIT'S FRONT PANEL.**

- 1** Open front panel of the indoor unit.
- 2** Using a screwdriver, open the wire box cover on the right side of the unit. This will reveal the terminal block.







Back view  
(For some units only)

Knock-out panel

**NOTE:**

- For the units with conduit tube to connect the cable, remove the big plastic knock-out panel to create a slot through which the conduit tube can be installed.
- For the units with five-core cable, remove the middle small plastic knock-out panel to create a slot through which the cable can exit.
- Use needle nose pliers if the plastic panel is too difficult to remove by hand.

- 3 Unscrew the cable clamp below the terminal block and place it to the side.
- 4 Facing the back of the unit, remove the plastic panel on the bottom left-hand side.
- 5 Feed the signal wire through this slot, from the back of the unit to the front.
- 6 Facing the front of the unit, connect the wire according to the indoor unit's wiring diagram, connect the u-lug and firmly screw each wire to its corresponding terminal.

**CAUTION**

**DO NOT MIX UP LIVE AND NULL WIRES**

This is dangerous, and can cause the air conditioning unit to malfunction.

- 7 After checking to make sure every connection is secure, use the cable clamp to fasten the signal cable to the unit. Screw the cable clamp down tightly.
- 8 Replace the wire cover on the front of the unit, and the plastic panel on the back.


**NOTE ABOUT WIRING**

**THE WIRING CONNECTION PROCESS MAY DIFFER SLIGHTLY BETWEEN UNITS AND REGIONS.**

**STEP 7: WRAP PIPING AND CABLES**

Before passing the piping, drain hose, and the signal cable through the wall hole, you must bundle them together to save space, protect them, and insulate them (Not applicable in North America).

- 1 Bundle the drain hose, refrigerant pipes, and signal cable as shown below:



**DRAIN HOSE MUST BE ON BOTTOM**

Make sure that the drain hose is at the bottom of the bundle. Putting the drain hose at the top of the bundle can cause the drain pan to overflow, which can lead to fire or water damage.

**DO NOT INTERTWINE SIGNAL CABLE WITH OTHER WIRES**

While bundling these items together, do not intertwine or cross the signal cable with any other wiring.

- 2 Using adhesive vinyl tape, attach the drain hose to the underside of the refrigerant pipes.
- 3 Using insulation tape, wrap the signal wire, refrigerant pipes, and drain hose tightly together. Double-check that all items are bundled.

**DO NOT WRAP ENDS OF PIPING**

When wrapping the bundle, keep the ends of the piping unwrapped. You need to access them to test for leaks at the end of the installation process (refer to **Electrical Checks and Leak Checks** section of this manual).


**STEP 8: MOUNT INDOOR UNIT**

**If you installed new connective piping to the outdoor unit, do the following:**

- 1 If you have already passed the refrigerant piping through the hole in the wall, proceed to Step 4.
- 2 Otherwise, double-check that the ends of the refrigerant pipes are sealed to prevent dirt or foreign materials from entering the pipes.
- 3 Slowly pass the wrapped bundle of refrigerant pipes, drain hose, and signal wire through the hole in the wall.
- 4 Hook the top of the indoor unit on the upper hook of the mounting plate.
- 5 Check that unit is hooked firmly on mounting by applying slight pressure to the left and right-hand sides of the unit. The unit should not jiggle or shift.
- 6 Using even pressure, push down on the bottom half of the unit. Keep pushing down until the unit snaps onto the hooks along the bottom of the mounting plate.
- 7 Again, check that the unit is firmly mounted by applying slight pressure to the left and the right-hand sides of the unit.

**If refrigerant piping is already embedded in the wall, do the following:**


- 1 Hook the top of the indoor unit on the upper hook of the mounting plate.
- 2 Use a bracket or wedge to prop up the unit, giving you enough room to connect the refrigerant piping, signal cable, and drain hose.



- 3 Connect drain hose and refrigerant piping (refer to Refrigerant Piping Connection section of this manual for instructions).
- 4 Keep pipe connection point exposed to perform the leak test (refer to Electrical Checks and Leak Checks section of this manual).
- 5 After the leak test, wrap the connection point with insulation tape.
- 6 Remove the bracket or wedge that is propping up the unit.
- 7 Using even pressure, push down on the bottom half of the unit. Keep pushing down until the unit snaps onto the hooks along the bottom of the mounting plate.


**UNIT IS ADJUSTABLE**

Keep in mind that the hooks on the mounting plate are smaller than the holes on the back of the unit. If you find that you don't have ample room to connect embedded pipes to the indoor unit, the unit can be adjusted left or right by about 30-50mm (1.18-1.96in), depending on the model.



# OUTDOOR UNIT INSTALLATION

Install the unit by following local codes and regulations, there may be differ slightly between different regions.



## INSTALLATION INSTRUCTIONS – OUTDOOR UNIT

### STEP 1: SELECT INSTALLATION LOCATION

Before installing the outdoor unit, you must choose an appropriate location. The following are standards that will help you choose an appropriate location for the unit.

Proper installation locations meet the following standards:

- ☑ Meets all spatial requirements shown in Installation Space Requirements above.
- ☑ Good air circulation and ventilation
- ☑ Firm and solid—the location can support the unit and will not vibrate
- ☑ Noise from the unit will not disturb others
- ☑ Protected from prolonged periods of direct sunlight or rain
- ☑ Where snowfall is anticipated, take appropriate measures to prevent ice buildup and coil damage.


### DO NOT install unit in the following locations:

- ⊗ Near an obstacle that will block air inlets and outlets
- ⊗ Near a public street, crowded areas, or where noise from the unit will disturb others
- ⊗ Near animals or plants that will be harmed by hot air discharge
- ⊗ Near any source of combustible gas
- ⊗ In a location that is exposed to large amounts of dust
- ⊗ In a location exposed to a excessive amounts of salty air

### SPECIAL CONSIDERATIONS FOR EXTREME WEATHER

#### If the unit is exposed to heavy wind:

Install unit so that air outlet fan is at a 90° angle to the direction of the wind. If needed, build a barrier in front of the unit to protect it from extremely heavy winds. See Figures below.



#### If the unit is frequently exposed to heavy rain or snow:

Build a shelter above the unit to protect it from the rain or snow. Be careful not to obstruct airflow around the unit.

#### If the unit is frequently exposed to salty air (seaside):

Use outdoor unit that is specially designed to resist corrosion.

# OUTDOOR UNIT INSTALLATION

(Continued)

### STEP 2: INSTALL DRAIN JOINT (HEAT PUMP UNIT ONLY)

Before bolting the outdoor unit in place, you must install the drain joint at the bottom of the unit.


Note that there are two different types of drain joints depending on the type of outdoor unit.

**If the drain joint comes with a rubber seal** (see Fig. A), do the following:

- 1 Fit the rubber seal on the end of the drain joint that will connect to the outdoor unit.
- 2 Insert the drain joint into the hole in the base pan of the unit.
- 3 Rotate the drain joint 90° until it clicks in place facing the front of the unit.
- 4 Connect a drain hose extension (not included) to the drain joint to redirect water from the unit during heating mode.

**If the drain joint doesn't come with a rubber seal** (see Fig. B), do the following:

- 1 Insert the drain joint into the hole in the base pan of the unit. The drain joint will click in place.
- 2 Connect a drain hose extension (not included) to the drain joint to redirect water from the unit during heating mode.



### ⚠ IN COLD CLIMATES



In cold climates, make sure that the drain hose is as vertical as possible to ensure swift water drainage. If water drains too slowly, it can freeze in the hose and flood the unit.

### STEP 3: ANCHOR OUTDOOR UNIT

The outdoor unit can be anchored to the ground or to a wall-mounted bracket with bolt(M10). Prepare the installation base of the unit according to the dimensions below.

### UNIT MOUNTING DIMENSIONS

The following is a list of different outdoor unit sizes and the distance between their mounting feet. Prepare the installation base of the unit according to the dimensions below.



**If you will install the unit on the ground or on a concrete mounting platform, do the following:**

- 1 Mark the positions for four expansion bolts based on dimensions chart.
- 2 Pre-drill holes for expansion bolts.
- 3 Place a nut on the end of each expansion bolt.
- 4 Hammer expansion bolts into the pre-drilled holes.
- 5 Remove the nuts from expansion bolts, and place outdoor unit on bolts.
- 6 Put washer on each expansion bolt, then replace the nuts.
- 7 Using a wrench, tighten each nut until snug.

Outdoor Unit Dimensions (in)	Mounting Dimensions	
	W × H × D	Distance A (in)
31.7" × 21.8" × 12.9 (805 × 554 × 330mm)	20.1 (511mm)	12.5 (317mm)
35.0" × 26.5" × 13.5 (890 × 673 × 342mm)	26.1 (663mm)	13.9 (354mm)
37.2" × 31.9" × 16.5 (946 × 810 × 420mm)	26.5 (673mm)	15.9 (403mm)

## ⚠ WARNING

**WHEN DRILLING INTO CONCRETE, EYE PROTECTION IS RECOMMENDED AT ALL TIMES.**

If you will install the unit on a wall-mounted bracket, do the following:

## ⚠ CAUTION

Make sure that the wall is made of solid brick, concrete, or of similarly strong material. **The wall must be able to support at least four times the weight of the unit.**

- 1 Mark the position of bracket holes based on dimensions chart.
- 2 Pre-drill the holes for the expansion bolts.
- 3 Place a washer and nut on the end of each expansion bolt.
- 4 Thread expansion bolts through holes in mounting brackets, put mounting brackets in position, and hammer expansion bolts into the wall.
- 5 Check that the mounting brackets are level.
- 6 Carefully lift unit and place its mounting feet on brackets.
- 7 Bolt the unit firmly to the brackets.
- 8 If allowed, install the unit with rubber gaskets to reduce vibrations and noise.

## STEP 4: CONNECT SIGNAL AND POWER CABLES

The outside unit's terminal block is protected by an electrical wiring cover on the side of the unit. A comprehensive wiring diagram is printed on the inside of the wiring cover.

## ⚠ WARNING

**BEFORE PERFORMING ANY ELECTRICAL OR WIRING WORK, TURN OFF THE MAIN POWER TO THE SYSTEM.**

### USE THE RIGHT CABLE

Please choose the right cable refer to "Cable types" on page 23.

### CHOOSE THE RIGHT CABLE SIZE

The size of the power supply cable, signal cable, fuse, and switch needed is determined by the maximum current of the unit. The maximum current is indicated on the nameplate located on the side panel of the unit.

**NOTE:** In North America, please choose the right cable size according to the Minimum Circuit Ampacity indicated on the nameplate of the unit.

- a. Using wire strippers, strip the rubber jacket from both ends of cable to reveal about 1.57 in (40mm) of the wires inside.
- b. Strip the insulation from the ends of the wires.
- c. Using a wire crimper, crimp u-lugs on the ends of the wires.


### PAY ATTENTION TO LIVE WIRE

While crimping wires, make sure you clearly distinguish the Live ("L") Wire from other wires.

## ⚠ WARNING

**ALL WIRING WORK MUST BE PERFORMED STRICTLY IN ACCORDANCE WITH THE WIRING DIAGRAM LOCATED INSIDE OF WIRE COVER OF THE OUTDOOR UNIT.**


- 1 Prepare the cable for connection:
- 2 Unscrew the electrical wiring cover and remove it.
- 3 Unscrew the cable clamp below the terminal block and place it to the side.
- 4 Connect the wire according to the wiring diagram, and firmly screw the u-lug of each wire to its corresponding terminal.
- 5 After checking to make sure every connection is secure, loop the wires around to prevent rain water from flowing into the terminal.
- 6 Using the cable clamp, fasten the cable to the unit. Screw the cable clamp down tightly.
- 7 Insulate unused wires with PVC electrical tape. Arrange them so that they do not touch any electrical or metal parts.
- 8 Replace the wire cover on the side of the unit, and screw it in place.



**NOTE:** If the cable clamp looks like the following, please select the appropriate through-hole according to the diameter of the wire.




Three size hole: Small, Large, Medium



When the cable is not fasten enough, use the buckle to prop it up, so it can be clamped tightly.

### In North America

- 1 Remove the wire cover from the unit by loosening the 3 screws.
- 2 Dismount caps on the conduit panel.
- 3 Temporarily mount the conduit tubes(not included) on the conduit panel.
- 4 Properly connect both the power supply and low voltage lines to the corresponding terminals on the terminal block.
- 5 Ground the unit in accordance with local codes.
- 6 Be sure to size each wire allowing several inches longer than the required length for wiring.
- 7 Use lock nuts to secure the conduit tubes.



Please select the appropriate through-hole according to the diameter of the wire.



# REFRIGERANT PIPING CONNECTION

When connecting refrigerant piping, **do not** let substances or gases other than the specified refrigerant enter the unit. The presence of other gases or substances will lower the unit's capacity, and can cause abnormally high pressure in the refrigeration cycle. This can cause explosion and injury.

## NOTE ON PIPE LENGTH

The length of refrigerant piping will affect the performance and energy efficiency of the unit. Nominal efficiency is tested on units with a pipe length of 16.5ft (5m) (In North America, the standard pipe length is 25' (7.5m)). **A minimum pipe run of 10' (3m) is required to minimize vibration & excessive noise.** Refer to the table below for specifications on the maximum length and drop height of piping.

Maximum Length and Drop Height of Refrigerant Piping per Unit Model


Model	Capacity (BTU/h)	Max. Length (ft)	Max. Drop Height (ft)
R410A Inverter Split Air Conditioner	< 15,000	82 (25m)	33 (10m)
	≥ 15,000 and < 24,000	98.5 (30m)	66 (20m)
	≥ 24,000 and < 36,000	164 (50m)	82 (25m)

## CONNECTION INSTRUCTIONS – REFRIGERANT PIPING

### STEP 1: CUT PIPES

When preparing refrigerant pipes, take extra care to cut and flare them properly. This will ensure efficient operation and minimize the need for future maintenance.

- 1 Measure the distance between the indoor and outdoor units.
- 2 Using a pipe cutter, cut the pipe a little longer than the measured distance.
- 3 Make sure that the pipe is cut at a perfect 90° angle.



### DO NOT DEFORM PIPE WHILE CUTTING

Be extra careful not to damage, dent, or deform the pipe while cutting. This will drastically reduce the heating efficiency of the unit.


# REFRIGERANT PIPING CONNECTION

(Continued)

### STEP 2: REMOVE BURRS

Burrs can affect the air-tight seal of refrigerant piping connection. They must be completely removed.


- 1 Hold the pipe at a downward angle to prevent burrs from falling into the pipe.
- 2 Using a reamer or deburring tool, remove all burrs from the cut section of the pipe.




### STEP 3: FLARE PIPE ENDS

Proper flaring is essential to achieve an airtight seal.

- 1 After removing burrs from cut pipe, seal the ends with PVC tape to prevent foreign materials from entering the pipe.
- 2 Sheath the pipe with insulating material.
- 3 Place flare nuts on both ends of pipe. Make sure they are facing in the right direction, because you can't put them on or change their direction after flaring.




- 4 Remove PVC tape from ends of pipe when ready to perform flaring work.
- 5 Clamp flare form on the end of the pipe. The end of the pipe must extend beyond the edge of the flare form in accordance with the dimensions shown in the table below.



- 6 Place flaring tool onto the form.

### PIPING EXTENSION BEYOND FLARE FORM

Outer Diameter of Pipe (in)	A (in)	
	Min.	Max.
Ø 0.25 (Ø 6.35mm)	0.0275 (0.7mm)	0.05 (1.3mm)
Ø 0.375 (Ø 9.52mm)	0.04 (1.0mm)	0.063 (1.6mm)
Ø 0.5 (Ø 12.7mm)	0.04 (1.0mm)	0.07 (1.8mm)
Ø 0.63 (Ø 16mm)	0.078 (2.0mm)	0.086 (2.2mm)
Ø 0.75 (Ø 19mm)	0.078 (2.0mm)	0.094 (2.4mm)




- 7 Turn the handle of the flaring tool clockwise until the pipe is fully flared.
- 8 Remove the flaring tool and flare form, then inspect the end of the pipe for cracks and even flaring.

### STEP 4: CONNECT PIPES

When connecting refrigerant pipes, be careful not to use excessive torque or to deform the piping in any way. You should first connect the low-pressure pipe, then the high-pressure pipe.


### MINIMUM BEND RADIUS

When bending connective refrigerant piping, the minimum bending radius is 4in (10cm).




## INSTRUCTIONS FOR CONNECTING PIPING TO INDOOR UNIT

- 1 Align the center of the two pipes that you will connect.





- Tighten the flare nut as tightly as possible by hand.
- Using a spanner, grip the nut on the unit tubing.
- While firmly gripping the nut on the unit tubing, use a torque wrench to tighten the flare nut according to the torque values in the Torque Requirements table below. Loosen the flaring nut slightly, then tighten again.




### TORQUE REQUIREMENTS

Outer Diameter of Pipe (in)	Tightening Torque	Flare shape
Ø 0.25 (Ø 6.35mm)	13 - 15 ft-lbs	
Ø 0.375 (Ø 9.52mm)	23 - 29 ft-lbs	
Ø 0.5 (Ø 12.7mm)	36 - 43 ft-lbs	
Ø 0.63 (Ø 16mm)	42 - 52 ft-lbs	
Ø 0.75 (Ø 19mm)	49 - 74 ft-lbs	

**DO NOT USE EXCESSIVE TORQUE** Excessive force can break the nut or damage the refrigerant piping. You must not exceed torque requirements shown in the table above.

## INSTRUCTIONS FOR CONNECTING PIPING TO OUTDOOR UNIT


- Unscrew the cover from the packed valve on the side of the outdoor unit.
- Remove protective caps from ends of valves.
- Align flared pipe end with each valve, and tighten the flare nut as tightly as possible by hand.
- Using a spanner, grip the body of the valve. Do not grip the nut that seals the service valve.



- While firmly gripping the body of the valve, use a torque wrench to tighten the flare nut according to the correct torque values.
- Loosen the flaring nut slightly, then tighten again.
- Repeat Steps 3 to 6 for the remaining pipe.

### ⚠ USE SPANNER TO GRIP MAIN BODY OF VALVE

Torque from tightening the flare nut can snap off other parts of valve.



## PREPARATIONS AND PRECAUTIONS

Air and foreign matter in the refrigerant circuit can cause abnormal rises in pressure, which can damage the air conditioner, reduce its efficiency, and cause injury. Use a vacuum pump and manifold gauge to evacuate the refrigerant circuit, removing any non-condensable gas and moisture from the system.


Evacuation should be performed upon initial installation and when unit is relocated.

## BEFORE PERFORMING EVACUATION


- Check to make sure the connective pipes between the indoor and outdoor units are connected properly.
- Check to make sure all wiring is connected properly.

## EVACUATION INSTRUCTIONS

- Connect the charge hose of the manifold gauge to service port on the outdoor unit's low pressure valve.
- Connect another charge hose from the manifold gauge to the vacuum pump.
- Open the Low Pressure side of the manifold gauge. Keep the High Pressure side closed.
- Turn on the vacuum pump to evacuate the system.
- Run the vacuum for at least 15 minutes, or until the Compound Meter reads -10 Pa (-76cmHG).



- Close the Low Pressure side of the manifold gauge, and turn off the vacuum pump.
- Wait for 5 minutes, then check that there has been no change in system pressure.
- If there is a change in system pressure, refer to Gas Leak Check section for information on how to check for leaks. If there is no change in system pressure, unscrew the cap from the packed valve (high pressure valve).
- Insert hexagonal wrench into the packed valve (high pressure valve) and open the valve by turning the wrench in a 1/4 counterclockwise turn. Listen for gas to exit the system, then close the valve after 5 seconds.
- Watch the Pressure Gauge for one minute to make sure that there is no change in pressure. The Pressure Gauge should read slightly higher than atmospheric pressure.



- Remove the charge hose from the service port.
- Using hexagonal wrench, fully open both the high pressure and low pressure valves.
- Tighten valve caps on all three valves (service port, high pressure, low pressure) by hand. You may tighten it further using a torque wrench if needed.

### ⚠ OPEN VALVE STEMS GENTLY

When opening valve stems, turn the hexagonal wrench until it hits against the stopper. Do not try to force the valve to open further.

## NOTE ON ADDING REFRIGERANT

Some systems require additional charging depending on pipe lengths. The standard pipe length varies according to local regulations. For example, in North America, the standard pipe length is 25' (7.5m).

In other areas, the standard pipe length is 16' (5m). The refrigerant should be charged from the service port on the outdoor unit's low pressure valve. The additional refrigerant to be charged can be calculated using the following formula:

### ADDITIONAL REFRIGERANT PER PIPE LENGTH

Connective Pipe Length (in)	Air Purging Method	Additional Refrigerant	
< Standard pipe length	Vacuum Pump	(9-18K)	(24K)
> Standard pipe length	Vacuum Pump	Liquid Side: $\emptyset 0.25$ ( $\emptyset 6.35\text{m}$ ) <b>R410A:</b> (Pipe length – standard length) $\times 0.16$ Oz/ft (Pipe length – standard length) $\times 15$ g/m	Liquid Side: $\emptyset 0.375$ ( $\emptyset 9.52\text{m}$ ) <b>R410A:</b> (Pipe length – standard length) $\times 0.32$ Oz/ft (Pipe length – standard length) $\times 30$ g/m

## CAUTION

**DO NOT** mix refrigerant types.

## BEFORE TEST RUN

Only perform test run after you have completed the following steps:

- Electrical Safety Checks – Confirm that the unit's electrical system is safe and operating properly
- Gas Leak Checks – Check all flare nut connections and confirm that the system is not leaking
- Confirm that gas and liquid (high and low pressure) valves are fully open

## ELECTRICAL SAFETY CHECKS

After installation, confirm that all electrical wiring is installed in accordance with local and national regulations, and according to the Installation Manual.

### BEFORE TEST RUN

#### Check Grounding Work

Measure grounding resistance by visual detection and with grounding resistance tester. Grounding resistance must be less than 0.1 $\Omega$ .

**NOTE:** This may not be required for some locations in North America.

### DURING TEST RUN

#### Check for Electrical Leakage

During the Test Run, use an electroprobe and multimeter to perform a comprehensive electrical leakage test.

If electrical leakage is detected, turn off the unit immediately and call a licensed electrician to find and resolve the cause of the leakage.

**NOTE:** This may not be required for some locations in North America.

### DURING TEST RUN

#### Check for Electrical Leakage

During the Test Run, use an electroprobe and multimeter to perform a comprehensive electrical leakage test.

If electrical leakage is detected, turn off the unit immediately and call a licensed electrician to find and resolve the cause of the leakage.

**NOTE:** This may not be required for some locations in North America.

## WARNING – RISK OF ELECTRIC SHOCK

**ALL WIRING MUST COMPLY WITH LOCAL AND NATIONAL ELECTRICAL CODES, AND MUST BE INSTALLED BY A LICENSED ELECTRICIAN.**

## GAS LEAK CHECKS

There are two different methods to check for gas leaks.

### Soap and Water Method


Using a soft brush, apply soapy water or liquid detergent to all pipe connection points on the indoor unit and outdoor unit. The presence of bubbles indicates a leak.

### Leak Detector Method

If using leak detector, refer to the device's operation manual for proper usage instructions.

## AFTER PERFORMING GAS LEAK CHECKS

After confirming that the all pipe connection points DO NOT leak, replace the valve cover on the outside unit.



- A: Low pressure stop valve
- B: High pressure stop valve
- C & D: Indoor unit flare nuts

# TEST RUN

## TEST RUN INSTRUCTIONS

You should perform the **Test Run** for at least 30 minutes.

- 1 Connect power to the unit.
- 2 Press the ON/OFF button on the remote control to turn it on.
- 3 Press the MODE button to scroll through the following functions, one at a time:
  - COOL –  
Select lowest possible temperature
  - HEAT –  
Select highest possible temperature
- 4 Let each function run for 5 minutes, and perform the following checks:

List of Checks to Perform	PASS/FAIL	
No electrical leakage		
Unit is properly grounded		
All electrical terminals properly covered		
Indoor and outdoor units are solidly installed		
All pipe connection points do not leak	Outdoor (2):	Indoor (2):
Water drains properly from drain hose		
All piping is properly insulated		
Unit performs COOL function properly		
Unit performs HEAT function properly		
Indoor unit louvers rotate properly		
Indoor unit responds to remote control		

## DOUBLE-CHECK PIPE CONNECTIONS


During operation, the pressure of the refrigerant circuit will increase. This may reveal leaks that were not present during your initial leak check. Take time during the Test Run to double-check that all refrigerant pipe connection points do not have leaks. Refer to **Gas Leak Check** section for instructions.

- 5 After the Test Run is successfully completed, and you confirm that all checks points in List of Checks to Perform have PASSED, do the following:
  - a. Using remote control, return unit to normal operating temperature.
  - b. Using insulation tape, wrap the indoor refrigerant pipe connections that you left uncovered during the indoor unit installation process.

## IF AMBIENT TEMPERATURE IS BELOW 61°F (16°C)

You can't use the remote control to turn on the COOL function when the ambient temperature is below 61°F (16°C). In this instance, you can use the MANUAL CONTROL button to test the COOL function.

- 1 Lift the front panel of the indoor unit, and raise it until it clicks in place.
- 2 The MANUAL CONTROL button is located on the right-hand side of the unit. Press it 2 times to select the COOL function.
- 3 Perform Test Run as normal.



# PACKING AND UNPACKING THE UNIT

## INSTRUCTIONS FOR PACKING AND UNPACKING THE UNIT:

### Indoor unit:

- 1 Cut the sealing tape on the carton with a knife, one cut on the left, one cut in the middle and one cut on the right.
- 2 Use the vice to take out the sealing nails on the top of the carton.
- 3 Open the carton.
- 4 Take out the middle support plate if it is included.
- 5 Take out the accessory package, and take out the connecting wire if it is included.
- 6 Lift the machine out of the carton and lay it flat.
- 7 Remove the left and right package foam or the upper and lower packaging foam, untie the packaging bag.

### Outdoor Unit:

- 1 Cut the packing belt.
- 2 Take the unit out of the carton.
- 3 Remove the foam from the unit.
- 4 Remove the packaging bag from the unit.

### Indoor unit:

- 1 Put the indoor unit into the packing bag.
- 2 Attach the left and right package foam or the upper and lower packaging foam to the unit.
- 3 Put the unit into the carton, then put accessory package in.
- 4 Close the carton and seal it with the tape.
- 5 Using the packing belt if necessary.

### Outdoor unit:

- 1 Put the outdoor unit into the packing bag.
- 2 Put the bottom foam into the box.
- 3 Put the unit into the carton, then put the upper packaging foam on the unit.
- 4 Close the carton and seal it with the tape.
- 5 Using the packing belt if necessary.

**NOTE:** Please keep all packaging items if you may need in the future.



5401 Dansher Road  
Countryside, IL 60525

844-4PA-AIRE | 844-472-2473 | [support@perfectaire.us](mailto:support@perfectaire.us)  
CANADA SUPPORT 877-997-2473 | [supportcanada@perfectaire.us](mailto:supportcanada@perfectaire.us)

[www.perfectaire.us](http://www.perfectaire.us)