

Type DHMH


Discharge Hood



P.O. Box 2300 Jacksonville, Florida 32203
 Phone: (904) 389-3646
 Fax: (904) 387-3449 • (904) 381-7560
 E-mail: fans@coolair.com
 Internet: www.coolair.com

Standard Features

- For use with American Coolair wall fans and Type MH wall housings
- Angled design directs the exhaust airstream and prevents the entry of rain into the building
- Heavy gauge galvanized steel
- Shipped knocked down
- Designed to be mounted directly to Type MH housings, or to the wall with optional flanges



Model	Dimensions in Inches			Metal Gauge
	A	B	C	
DHMH7-8	14 1/2	13	17 3/8	22
DHMH10-12	18 1/2	15	21 3/8	22
DHMH14-16	22 1/2	17	25 3/8	22
DHMH18-20	26 1/2	18 7/8	29 3/8	22
DHMH24	32 1/2	22	35 3/8	20
DHMH30	38 1/2	24 5/8	41 3/8	20
DHMH36	44 1/2	27 5/8	47 3/8	18
DHMH42	50 1/2	30 1/4	53 3/8	18
DHMH48	56 1/2	32 7/8	59 1/2	18
DHMH54	62 1/2	35 3/4	65 5/8	18
DHMH60	68 1/2	35 3/4	71 5/8	18