### Model 6KK17

# Air-Cooled Portable Air Conditioner Submittal Data

# c Ustree Us

#### SD-6KK17-2

#### STANDARD FEATURES

- 16,800 Btu Cooling Capacity
- Spot-Cool / Room-Cool Thermostat Settings
- Internally Insulated with Fiberglass Insulation
- Thermostatic Control with Multi-Speed Fan
- Double Shaft Motor for Two Fans
- R410A Refrigerant
- Optional Easy Install Condensate Pump Kit with Overflow Protection
- 115V/1 Phase
- Directional Nozzles (2)
- · Heavy Duty Twin Wheel Casters for Portability
- Self-Diagnostic System
- Off-Timer
- Washable Filters

#### **SAFETY DEVICES**

- Compressor Overload Protection
- Anti-freezing Thermistor
- Full Drain Tank Switch
- Automatic Restart (Power Interruption)
- Compressor Time Delay Program
- High Pressure Switch

#### **SPECIFICATIONS**

Model Number	6KK17
Cooling Capacity	16,800 Btu/hr
Cooling Test Conditions	95°F
Voltage/Phase/Hz	115/1/60
Amperage	15.5
Fuse Size	20 Amps*
LCDI Plug Configuration	NEMA 5-20P
Power Cord Length	6′
Refrigerant Type	R410A
Dimensions	40.9"H x 20.5"W x 26"D
Net Weight	190 Lbs
Shipping Weight	205 Lbs
Condensate Tank Capacity	3.17 Gal

<sup>\*</sup>Time delay fuses and circuit breakers are recommended



#### **ADDITIONAL SPECIFICATIONS**

Ambient Temperature Range	64 - 113°F	
Setting Temperature (Room Cool)	64 - 86°F	
Setting Temperature (Spot Cool)	32 - 86°F	
Application Area Ft <sup>2</sup> (Room Cool Mode)	430	
Refrigerant Type / Ounces	R410A / 35.5	
Design Pressure High/Low	450 / 250 PSIG	
Indoor Air Flow High/Low	470 / 400 CFM	
Hot Air Duct Diameter	12"	
Maximum Exhaust Duct Length	50'	
Condenser Air Flow	1250 / 1120 CFM	
FLA	15.5 Amps	
Max Duct Length: Cold Air Supply	30 ft.	
Max Duct Length: Hot Air Discharge	50 ft.	
Duct Connection Hot Air Discharge	12 in.	
Drain Type	Bucket (4 gal.)	

KOL	DИ	VE


260 North Elm St.

Westfield, MA 01085 Phone: 413-564-5520 Fax: 413-564-5815

<b>Fax:</b> 413-564-5815	
www.Koldwave.com	1


Project:		Da	ate:
-			
Submitted			
For:	□ Reference	□Approval	□Construction
	ation:		
Schedule Ni			






#### Control Panel Key Buttons:

- 1. Power
- 2. Blower
- 3. Spot/Cool
- 4. Room/Cool
- 5. Set Temperature
- 6. Alarm
- 7. Current Temperature
- 8. Target Temperature






Back and Left Side View


## **DIMENSIONS (In Inches)**

**COMPONENT PARTS** 





#### **ASSEMBLY**



#### POWER CORD HOLDER

- 1. Take out the cord holder from the accessory box.
- 2. Place the cord holder on the back side of air conditioner.
- 3. Use screws (enclosed inside of accessory box with cord holder) to install the cord holder on the air conditioner as shown in Figure 1.




Figure 2


#### TOP FAN EXHAUST FLANGE

- 1. Remove the top fan exhaust flange from carton.
- 2. Place the top fan exhaust flange on the top of air conditioner.
- 3. Use screws (enclosed inside of box with the top fan exhaust flange) to install the top fan exhaust flange on air conditioner as shown in Figure 2.



#### DISCHARGE DUCTS/SUPPLY AIR DUCT

- 1. Remove cool air outlet hose(s) from carton.
- 2. Place the cool air outlet hose(s) on the front top of air conditioner.
- 3. Use screws (enclosed inside of box install the cool air outlet hose(s) on with cool air outlet hose(s) to the air conditioner as shown in Figure 3.



#### AMBIENT AIR ADAPTER (Optional)

An ambient air adapter can be purchased separately. Air adapter fits over the condenser to duct condenser air to the unit to improve cooling efficiency.

- 1. Remove the Filter("A")
- 2. Check the Filter("C") is inserted properly in Intake Warm Air Duct("B")
- 3. Install "B" which contains "C" by using driver with enclosed bolts(6EA) as Figure 4.





# **Accessory Parts**

Part Name	Part Number
Condensate pump kit (115V)	SA057-0072
Condenser plenum/return air adapter	SA076-4004
Remote Controller (26 ft with line)	SA076-4006
16 FT Temperature Sensor	SA076-4007
Cool air duct connecting flange (D5", L3")	SA076-4008
Long cool air duct assembly (D5", L40")	SA076-4009
Evaporator plenum	SA076-4005
Condenser return/discharge Kit	SA076-3635
Replacement washable filter, evaporator	KWPCFLT-05E
Replacement washable filter, condenser	KWPCFLT-05C