

FIREPLACE MANTEL



IMPORTANT

THIS INSTRUCTION CONTAINS IMPORTANT SAFETY INFORMATION.

PLEASE READ AND KEEP FOR FUTURE REFERENCE.




WARNING



- Do not allow children to climb on unit.
- Serious or fatal crushing injuries can occur from furniture tip-over, to prevent this furniture from tipping over it must be permanently fixed to the wall.
- Fixing devices for the wall are not included since different wall materials require different types of fixing devices. Use fixing devices suitable for the walls in your home. For advice on suitable fixing systems, contact your local specialized dealer.
- This unit contains small parts which can be swallowed by children and pets. Keep children and pets away during assembly. To avoid danger of suffocation always keep plastic bags away from children and pets.

BEFORE YOU START


- Separate and count all parts and hardware.
- Have the following tool: Flat head Screwdriver, #2 Philips Head Screwdriver.
- If using a power tool, please be ware to slow down and stop when screw is tight. Failure to do so may result in stripping the screw.
- Requires two people for assembly.
- The product is KD construction. Do not fully tighten the bolts before all are completely lined up and inserted into holes. Loosen the bolts and make sure all bolts are lined up and inserted into the holes.




CAM LOCK FASTENING SYSTEM



2










4



Make proper orientation of
CAM LOCK when inserting CAM BOLT


HARDWARE PART LIST

NOT SHOW ACTUAL SIZE



BOARD IDENTIFICATION

NOT SHOW ACTUAL SIZE











PARTS LIST

NOT SHOW ACTUAL SIZE





Parts List

Part No.	Description	Qty.
A	Top	1
B	Upper Center Shelf	1
	Lower Center Shelf	1
C	Lower Firebox Trim	1
	Upper Firebox Trim	1
D	Base	1
E	Left Outside Panel	1
	Right Outside Panel	1
F	Left Front Panel	1
	Right Front Pane	1
G	Left Firebox Trim	1
	Right Firebox Trim	1
H	Firebox Support Panel	2






STEP 1






STEP 2






STEP 3






STEP 4






STEP 5




STEP 6






STEP 7



STEP 8







STEP 9



Anti-Topple Device Installation

 **CAUTION**



Maintenance

To clean and care for your furniture:

- Use a soft, clean cloth that will not scratch the surface when dusting.
- Use of furniture polishes is not necessary. Should you choose to use polishes, test first in an inconspicuous area.
- Using solvents of any kind on your furniture may damage the finish.
- Never use water to clean your furniture as it may cause damage to the finish.
- Always use coasters under beverage glasses and flowerpots.
- Liquid spills should be removed immediately. Using a soft clean cloth, blot the spill gently. Avoid rubbing.
- Always use protective pads under hot dishes and plates. Heat can cause chemical changes that may create spotting within the furniture finish.
- Stains or marks from crayons or ink markers will be difficult to remove.
- In the event that your furniture is stained or otherwise damaged during use, please contact us:.
- Check bolts/screws periodically and tighten them if necessary.
- It is best to keep your furniture in a climate-controlled environment. Extreme temperature and humidity changes can cause fading, warping, shrinking and splitting of wood. It is advised to keep furniture away from direct sunlight as sun may damage the finish.
- Proper care and cleaning at home will extend the life of your purchase. Following these important and helpful tips will enhance your furniture as it ages.

Your assembly should now be complete.

Thank you for your purchase.

**“KEEP THESE INSTRUCTIONS FOR FURTHER
REFERENCE”**